

4LZ-2.0D Combine Harvester Instruction Manual



(Please read this manual carefully before operating)

AGCO DAFENG (YANZHOU) AGRICULTURAL MACHINERY CO.,LTD.
ADD: No.1 Dafeng Road Yanzhou City Shandong Province, China
Tel/Fax: 0086-537-3834406

PREFACE

This user guide book introduce safety points, specification basic structure, operation rules, maintenance, lubrication and other related notes of 4LZ-2.0D combine harvester systematically. Please read it carefully and understand the basic principle of the machine before operation it.

Must protect this book carefully for it's undividable part of the machine, it play a import role in operating and maintaining the machine correctly and safely.

Any operator of the machine must learn this book and be familiar of its character and operation rules, grasp the maintenance skill, It is prohibited to deform the machine by users to avoid anything that is harmful to the machine or people.

To improve the quality, function, and safety, some parts may be changed, and we will not give another notice. So please pay attention to the contents, pictures, illustrations and other related things, which may be not the same as the products.

Contents

Points for Safety

I. Safety Operation

1. Only the driver has been trained in operation of the combined harvester and holds the valid driving license issued by the agricultural machinery supervision institute can operate the harvester.

2. When starting the combined harvester, nobody is allowed to stand 3 meters far from the front cutting table and the sides of the machine. It is strictly prohibited to stretch hands out into dangerous places such as the cutter, reel and straw discharge port so as to prevent injury.

3. It is strictly prohibited to enter into the grain case when the machine is running. If blockage happens, it is strictly prohibited to dig by hands before the engine is dead so as to prevent accident.

4. When repairing the machine and lifting the cutting table, it should take out the lock cover for blue oil cylinder locked on the beam of the cutting table to lock the oil cylinder (mount lock pin and cotter pin) to avoid accidentally falling of the cutting table.

5. The extinguisher is the first-choice protection tool of the operator. When the harvester is in operation, it should carry the extinguisher which is placed in front of the cover of the engine (the large grain case is in front of the grain case).

The application way of the extinguisher is: 1. Pull out the security lock; 2. Press down the handle. When above 1 and 2 items are finished, aim the spray port at where extinguishing is needed, gas in the cylinder can be sprayed to wipe out the fire.

The extinguisher should be refilled if it is opened or the pointer is lower than the green area.

The working pressure of the extinguisher (20°C): 1.2 Mpa.

The extinguishing agent: ammonium phosphate salt.

6. It should close the safety cover before starting the engine, and it is strictly prohibited to open or take away the safety cover after the engine is started.

7. Before starting the engine, check the speed shift lever to see if it is at the neutral position, if the work clutch and grain-discharge clutch are at off position, otherwise it is strictly prohibited to start.

8. Look around the machine and only after confirming that everything roundabout is safe can the engine be started.

9. When the machine is running, nobody is allowed to stand against the straw discharge port so as to prevent injury hurt by splashing objects.

10. When transferring on the field nobody is allowed to ride except the driver.

11. If the water tank is overheated and water is boiled, it is strictly prohibited to open the cover of the water tank, which can only be opened by wrapping it with wet rag and turning it slowly when nobody is roundabout after it is cooled.

12. When the combined harvester is loaded on or unloaded from the truck, the one end of the gangboard should be fastened with the side board of the platform of the truck, the other end should be placed on the ground with the included angle between the gangboard and the ground no larger than 30% ($<16^{\circ} 41'$). Each piece of the gangboard should have a width 50 mm larger than that of the track and enough strength and aims right against the track. When loading or unloading only the driver should stay on the harvester to run forward with low speed and small accelerator under the instruction of others. No direction turning is allowed on the gangboard.

13. The machine cannot run on the road with inclining angle between the left side and the right side over 8° so as to avoid turnover.

14. When making welding, all straw bits and oily dirt around the welded part should be wiped out so as to prevent catching fire.

15. It is strictly prohibited to remove trouble before the engine is dead, and to open the top cover of the roller when the engine is not dead and still running.

16. In case the roller is blocked, stop the engine immediately and open the top cover of the roller, it is not allowed to turn the teeth bar of the roller or to pull the belt of the roller by hands to make repair. When turning the roller, it should use the special tool for turning threshing mechanism directly connected behind the harvester, insert two teeth of the special tool into two holes of the spoke of the belt pulley of the roller and turn the handle slowly.

17. In case more than two persons make repair or adjustment, they should be harmonized. If turning the part of the machine, it should notify the other person.

18. Driver who is drunk, less slept or ill, pregnant women and minor are not allowed to operate the machine.

II. Marks of Safety

In order to use the machine safely and avoid human injury accident, customer is pleased to carefully understand various kinds of safety marks posted on the machine and practically observe stipulations. Safety marks should be clean without damage and renew then if damaged. The new safety marks can be bought from the distributors or ask for from the company by mail.



Description of Various Kinds of Marks

Description on Concerned Safety Logos and Posted Location:

1) Cutting table



2) Driving station



3) Water tank



4) Protection cover



5) Threshing roller cover



6) Bran outlet




7) Grass outlet



8) Surface of the auger



9) Grain tank



Chapter 1 General Description

Name of Product: Model 4LZ-2.0D Track Self-Walking Full-Feed Combined Harvester

The machine is a new rice/wheat dual-purpose combined harvester, compared with the former generation product of the company it has advantages of high efficiency, low ground pressure and good reliability, and can fulfil jobs of cutting, conveying, threshing, separating, cleaning and grain discharging of rice and wheat (barley) in water field with soil depth of 25 cm and dry field, and obtain grains directly. All straw and husk are spread on the field.

The machine has a series of patent technique with obvious characteristics as follows:

1. Continuously Variable Transmission, one-handle control, hydraulic steering make operation easy and convenient.
 2. Wide track and high ground clearance is much suitable for work on paddy field.
 3. Hanging support wheels, dual pipe supported guide wheel and wearable driving wheel are three high reliable lines of defense from mud.
 4. The super high lifting height of cutting table is convenient for down slope and ridge cross.
 5. The super wide conveying groove make conveying smooth with little noise.
 6. Dual threshing case with broad diameter, vibrating screen with screen plates adjustable and lifting/conveying re-threshing auger guarantee the small loss and high cleanness.
 7. Large volume grain tank make grain collecting operation easy and convenient.
 8. New model of driving platform, open-type engine cover make cleaning and repair much easier.
- In a word, this machine with unique structure, beautiful outlook, easy operation, reliability and safety, high rate of crossing paddy field, energy saving and high efficiency and stable characteristic is the most ideal harvest machine for the area of paddy and wheat, especially for the paddy field.

Chapter 2 Main Technical Specifications

Section 1 Model of Product

1. Model :4LZ-2.0D
2. Product Name: 4LZ-2.0D Track Self-Walking Full-Feed Combine Harvester

Section 2 Main Technical specifications

The technical specifications of the machine are in accordance with following standards: GB/T8097-1996 <Harvest Machines Combined Harvester Test Methods>, GB10395.7-1999<Agriculture and Forest Tractor and Machinery Lawn and Horticulture Power Motive Machinery Safety Mark and Danger Logos General Rules>, JB5117-1991 <General Technical Conditions of Combined Harvester of Grain.

1. Main Specification Indices

In case of the maximum continuous feed volume, no grass on the cutting line and crops being upright, the ratio of grain/straw of wheat is 0.6~1.2, moisture rate of grain is 12%~20%; the ratio of grain/straw of rice is 1.0~2.4, while, moisture rate of grain is 15%~28%. The operation feature can reach following main indices:

Item	Indices (%)		
	Rice	Wheat	Cole
Total Loss Rate	≤3.0	≤1.2	≤8
Impurity Rate	≤2.0	≤2.0	≤6
Breakage Rate	≤1.5	≤1.0	≤0.5
Efficiency of Reliability	≥93%		


2. Technical Specifications

S/N	Item		Unit	Size	
1	Structure Style		/	Track Self-Walking Full-Feed	
2	Applicability For Crop (Physical Height)		mm	Paddy, wheat: 500-1200	Cole:601-700
3	Power Motive		kw/rpm	55/2400	
4	Productivity of Pure Working Hour		hm ² /h	Paddy,wheat:0.2-0.47	Cole:0.1-0.3
5	Fuel Oil Consumption per Hectare		kg/hm ²	≤38	≤30
6	Outline Sizes in Working State (L×W×H)		mm	4750×2350×2360	Cole 5020×2450×2300
7	Structural Weight		kg	Paddy, wheat:2350	Cole: 2450
8	Cutting Width		mm	2000	
9	Feed Volume		kg/s	Paddy, wheat:2.0	Cole: 1.5
10	Minimum Gap of Off-Ground		mm	240	
11	Style of Swerve		/	Hydraulic Style	
12	Shift Modality		/	Automatic Mechanical Transmission +HST Hydraulic Continuously Variable Transmission	
13	Speed of Operation Forward		m/s	0~2.88, 0~4.54, 0~7.56	
14	Stroke of Cutter		mm	II type	
15	Auger Style of Cutting Table		/	Spiral Conveying	
16	Outer Diameter of Auger of Cutting		mm	Φ470	
17	Style of Reel		/	Eccentric Style	
18	Diameter of Reel		mm	Φ900	
19	No. of Plates of Reel		PCS	5	
20	Conveyor Belt Style		/	Rake-Teeth Style	
21	Threshing Roller Style		/	Tangential flow + Axial flow	
22	Size of Threshing Roller(O.D. ×L)	Front Roller	mm	Φ540×650	
		Rear Roller	mm	Φ540×1285	
23	Concave Style		/	Grid Screen×2	
24	Angle Range of Concave		(°)	227 °	
25	Fan Style		/	Centrifugal	
26	Diameter of Fan		mm	Φ328	
27	Diameter of Grain Discharge auger		mm	Φ123	
28	Crew Distance of Grain Discharge auger		mm	105	
29	Re-Threshed Style		/	Back to Threshing Roller directly	
30	Grain Receiving Style		/	Manual/Hydraulic	
31	Clearance between Argue of Cutting		mm	15-18	
32	Track		mm	400(or 450) ×90×48	

Note: This machine need cole spare when harvest cole.

Chapter 3 Construction and Working Course of the Combined Harvester


The combined harvester consists of three major parts: cutting and conveying part, threshing part and walking part. The cutting and conveying part locates at the far front and consists of cutting table and conveying groove; the threshing part locates at the rear side, consist of threshing and separating device, auger grain discharge device and grain case; the walking part locates at the lower part of the machine, consists of frame, engine, gearbox and wheels and track. In addition there are hydraulic system, electric system and Operation system etc.



1. Lifting Auger 2. Grain Collecting Box 3. Rear Threshing Roller 4. Front Threshing Roller
5. Operation System 6. Electric System 7. Conveying Groove 8. Telescopic teeth 9. Spiral conveyor for cutting table 10. Stand Cutter 11. Auxiliary plate 12. Reciprocal cutter 13. Spreading box 14. Dividers 15. Reel 16. Cutter table 17. Track 18. Bear Weight Wheel 19. Lifting Auger 20. Footplate 21. Frame back 22. Footplate

Figure 1 Construction View of 4LZ-2.0D Rice/Wheat Combined Harvester

Shown as Figure 1, when the machine is in operation, the dividers (14) on both sides of the cutting table can divide non-cutting crop from the crop to be cut, which is cut by the reciprocal cutter (12) on the cutting table with the support of the reel (15). The ear part is pushed by the spiral conveyor for cutting table (9) and the auxiliary plate (11) to the left side of the cutting table and putting back by the telescopic teeth (8) and grasped by the scraper at the conveying groove (7) and sent to the threshing roller.




1. Reciprocal Vibration Screen 2. Re-Threshed System 3. Residues Rising/Conveying Auger
 4. Grain Rising/Conveying Auger 5. Rear Threshing Roller Top Cover 6. Rear Threshing Roller 7. Rear Concave Screen 8. Fan 9. Grain Collecting Case 10. Front Threshing Roller
 11. Front Threshing Roller Top Cover 12. Front Concave Screen 13. Threshing Frame

Figure 2 Threshing System of 4LZ-2.0D Rice/Wheat Combined Harvester

Shown as Figure 2, the crop is axially and spirally moved under the front threshing rollers (10) and rear threshing roller (6), front concave screen (12) and rear concave screen (7), and front threshing roller top cover (11) and rear threshing roller (6). During the course grains drop down and straw is deformed. Grains are separated from some husk and short straw through the concave under the role of the centrifugal force. Light impurities are blown off the machine by blowing of the fan (8) as well as the role of the reciprocal vibration screen (1) while grains drop into horizontal auger and the broken fringe drop into horizontal auger. Grains in horizontal auger are sent to the grain collecting case (9) by the lifting auger (4) while grains in horizontal auger are re-threshed by the re-threshed roller, sent by rising/conveying auger (3) to be re-threshed again by the rear roller. Straw and leaves that do not pass through the concave are discharged out from the discharge port at the rear side.

Chapter 4 Application of the Combined Harvester

Section 1 Rules of Operation



Shown as Figure 3:

1. Handle for Work Clutch 2. Turn-Off Switch 3. Auxiliary Gear-Shift Handle 4. Lock For Brake Plate 5. Main Gear-Shift Handle 6. Front Work Lamp Switch 7. Handle for Throttle Adjustment 8. Receiving Grain Lamp Switch 9. Meter Assembly 10. Rear Work Lamp Switch 11. Turn lamp Switch 12. Horn Button 13. Brake Plate 14. Turning&Cutting table up/down Switch 15. Key Switch 16. Lift Handle of Reel

The detailed operation rules are as follows:

1. Before the Engine is Starting:

The main gear-shift handle (5) is at neutral position, the handle of work clutch (1) is at disengagement position and the turn-off switch (2) at the close position. The lock for brake plate (13) is at the disconnection position.

Figure 3 Plan Drawing of Operation Table

2. Start the Engine:

Insert the key into the key switch (15), turn it clockwise from the original position (0) to "I" connection position where the battery is connected with the main circuit of the motor, then turn it clockwise to "II" start position where the motor runs and drives the engine to start. After the engine is started, reset the key quickly from "II" position to 'I' position and the pointer of the ampere meter swings to "+" polarity. The key should stay at 'I' connection position to charge the battery otherwise the motor could be burnt out or gears could be damaged. The sustained time for each start should be no long than 5 seconds. If start is unsuccessful, restart after two minutes to prevent the motor to be burnt out due to overheat.

Notes:

- 1) Before starting the machine, back to persons roundabout and start the switch after confirming safety and nobody within 20 m after the harvester.
- 2) Strictly forbid to start the machine if the main gear-shift handle is not at the neutral position.

3. Start Walking:

Choose the Auxiliary Gear-Shift gear when the speed of the diesel engine rises up over 1800 rpm.

On the flat ground, disconnect the brake plate lock, push forward the main gear-shift handle slowly, the machine runs forward. More push forward, faster the machine runs forward. If running backward is needed, pull the main gear-shift handle to the neutral position to stop running of the machine, then press the button on the hydraulic operation handle by the thumb and pull it back. More pull backward, faster the machine runs backward.

On the slope, trample the brake plate, disconnect the brake plate lock, push forward the main gear-shift handle slowly, at the same time set free the brake plate, the machine runs forward. On the contrary, pull backward the main gear-shift handle at the same time set free brake plate slowly, the machine runs backward.

Notes:

- 1) It is strictly prohibited to run on the field at high speed (high speed is used when walking on plain highway) otherwise overload can badly affect the service life of the infinitive variable gearbox.
- 2) For infinitive variable gear style, it is strictly prohibited to press the button on the hydraulic operation handle and directly pull it back quickly when running at high speed so as to avoid damage of input or output shafts of the infinitive variable gearbox.

4. Passing Through the Ridge and Ditch:

It should pass through ridge and ditch vertically. In case passing through ridge and ditch diagonally be included angle should be larger than 70° so as to avoid turnover of the machine or drop of the track. It should pass ridge with large accelerator and low speed which is quite different with the mechanical gear-shift style otherwise it cannot pass through the ridge due to small accelerator and less power. When the gravity center of the machine moves on the ridge, it should pull the main gear-shift handle to the neutral position (stepping the walking clutch for the mechanical gear-shift style) to make the front half of the machine drop down by its inertia can it continuously run, For the ridge higher than 15 cm, it should be spaded out or be padded into a slope.

5. Turning:

When turning to left, pull the left-turning handle to disengage the left jaw. If sudden turn is needed, continue to pull the left-turning handle to completely disengage the jaw and to press tightly the friction disc to make one-sided brake. The size of the turning radius can be changed by the size of pulling force. When turning to right, pull the right-turning handle.

Notes:

- 1) When turning or reversing look if somebody is roundabout so as to make safe operation. It is strictly prohibited to turn at high speed.
- 2) Normally do not make the turning jaw disengage or engage frequently so as to reduce times of impact, and to avoid early worn-out of the turning jaw.

6. Protect the Track

The normal service life of the rubber track is about 800-1000 hours. It should not run at high speed on uneven road or on the field. It should be loaded on the truck if transfer distance is

longer than 4km so as to prevent early worn-out of the track. Do not run on the road with sharp objects to avoid scratch of the track, water penetrating and rust of steel wire of the track, early discard of the track. Do not turn on the concave road to avoid drop of the track.

The three guarantees period is for 6 months.

7. Stop on the Slope:

Trample the brake plate (13) with the left foot, the concave groove of the brake plate lock (4) fastened brake plate (13). (then both left and right jaws are disengaged and the brake is braked). If continuing to run forward, please operate as the above No.3 terms content.

8. Lift Up/Down the Cutting Table:

Pull the lift handle of the cutting table (14) backward, the cutting table is rising up; push it forward the cutting table is lowered down.

9. Lift Up/Down the Reel

Pull the lift handle of the reel (16) backward, the reel is rising up; push it forward the reel is lowered down.

10. Reasonably Select Work Speed:

When working on wet and soft field or dry field with yield of crop over 500kg per mu, it should take Stow I speed to work, or Fast II speed if yield of crop below 500kg per mu. When work in mud field or when crop is lodged, it should take Slow I speed to work.

Note: High gear speeds (High HI) are strictly prohibited to use for working.

11. Some Point Specially Mentioned:

- a. The combined harvester is not allowed to work continuously for over 10 hours. Normally it should stop for 2 hours if work for 8-10 hours otherwise the oil seal shall be aged early, the hydraulic oil shall be thinned or deteriorated or the tallow shall be melted due to high temperature.
- b. The machine can not harvest when crops is not mature enough and has dew in the morning or at night.
- c. When working the driver should concentrate his attention to hear carefully running of all parts. If blockage is found it should be removed in time. If the engine emits black smoke under overload, it should temporarily stop running and continue to cut until the load of threshing becomes normal.
- d. As threshing and separating consume much energy it should ensure the engine to have enough cooling water. The impurities on the outer cover of the radiator of the engine should be cleared out every two working hours. If the engine smokes many times, it should reduce speed to run forward or suitably reduce the cutting width to cut only by the left side of the cutting table.
- e. If abnormal sound from the thresher is heard, stop the machine in time to check if internal parts are damaged. If so, never apply the power to make the thresher running because it can cause major accident due to the speed of the roller of the thresher is as high as over 800 rpm.
- f. When the work is finished, push all grains out from the grain discharge auger the disengage the work clutch, shift the gear to the neutral position, close the accelerator gradually to mm off the engine and open the switch blade of power supply.

- g. When working, only one driver is allowed on the machine (one added grain receiver for the small grain case style) and extra person is not allowed.
- h. When the combined harvester transfers on the fields, the work clutch should be disengaged.

Section 2 Adjustment Before Cutting

Before making harvest of crop in fields, it should make adjustment on the harvester before cutting.

I. Adjustment of the Cutting Height of the Cutting Table

1. Adjustment for cutting height

The cutting height of the cutting table is according as local custom. In principle, when the ear part of cut crop has a length of 45cm-55cm under the horizontal cutting table, the synthetic result is the best. When natural height of the crop is below 50 cm (over the use rang), we must control the stubble below 7cm, otherwise the feeding entrance would be jammed as the cutted crop was too short.




Figure 4 The mobile blade location adjustment for Cutter

2. Adjustment for cutting clearance

It is best that the front of the cutting clearance should be 0-0.5 mm, the rear of the cutting clearance should be 0.5 mm-1.3mm. It is possible that the cutter can not partition the crop or increase the cutting pressure when the front clearance of the cutter more than 1mm, so it must readjust. Please turn over the friction disk or put one piece of flake under of the friction disk when do the adjustment.

3. The adjustment for the mobile blade location

When leaving the factory, the mobile blade location is suitable. It maybe readjust the mobile blade location when replace the mobile blade (2) or long pitman. The sickle uses knife theoretically the route or distance of travel responds to between protecting two point of edge implement (1), the bit centre being that the crank uses knife during the period of upper the dead

center going ahead responds to and the point protecting edge implement (1) right is straight face to face, the crank bit using knife time the dead center going ahead in time centre should move the point arriving at and protecting the edge implement (1) left to being straight.

II. Adjustment of the reel, see Figure 5




Figure 5 Adjustment for reel

1. Adjust the Height of the Reel

For upright crop, turn the reel (5) to the lowest position just aiming the two thirds of the height of crop cut by the cutter of the horizontal cutting table; for lodged crop, when turning the reel finger to the lowest position, it shall just pass through above the cutter of the horizontal cutting table. Pull or push the lift handle of the reel to the required position and release it, the hydraulic valve can keep pressure locked automatically.

2. Adjust the Front or Rear Position of the Reel

Move the connection holes of the eccentric adjustment fixing seat and the suspension beam (2) on both sides of the reel, the front or rear position of the reel can be adjusted. Usually, the reel location is in the middle of the hole; for high straw or lodged, the reel should be put forward; when harvest the crops under 60cm, the reel should be put backward.

3. Adjustment of Inclining Angle of the Reel Finger

When harvesting upright or slight lodged crop, the reel fingers (5) are normally downward so as to reduce knock on ears by the reel finger. For thicker crop to add laying function, the reel fingers can be tilting upward. When harvesting loose or lodged drop, the reel fingers can be tilted backward to add the function to support crop.

When adjustment, loosen the connection nut of the eccentric adjustment plate (3) and the

eccentric plate to adjust suitable tilting angle of the reel finger. After adjustment tighten the bolt. When adjusting the reel, take care that the reel finger cannot touch the cutting table and the spiral conveyor of the cutting table.

Note: When leaving the factory, the mounting position of the reel is suitable for crop with height of 70-90 cm. In case crop is dense and yield is high, after adjustment of front or rear position of the reel, V-shaped driving belt should be readjusted and the tension wheel should be tensioned.

III. Adjustment of the Spiral Conveyor of the Cutting Table, see Figure 6




Figure 6 Adjustment of the Spiral Conveyor of the Cutting Table

The spiral conveyor of the cutting table has been adjusted when leaving tile factory. When the extension lever turns to the side of the feed port of the conveyor groove, it should be retracted to the shortest length; when turning to the side of the base plate of the cutting table it should have a gap larger than 5 mm with the base plate. When adjustment is needed, first loosen the nut(3) on the left support seat of the spiral conveyor move the eccentric axle adjustment block(4) to reach the requirement then lock the nut (see Figure 6).

Before operation, check the extension lever if it can be moved freely in the nylon fixing seat, it bolt of the fixing seat is locked and if limit screw and nut are adjusted well and locked.

IV. Adjustment of the Chain of the Conveyor Groove, see Figure 7




Figure 7 Adjustment of the Chain

After using for a period of time, the pin roils of the chain in the conveyor groove are worn out and the chain is lengthened, when the chains are different length it should adjust the tension support rod.

Note: When adjusting, two chains should be even and identical. After tension, the conveyor plate (1) can not be over the plate (2) of cutting table.

V. Adjustment of the concave plate gap, see Figure 8




Figure 8 Adjustment of the concave plate gap


The machine adopts double-row toothed bar axial flow roller. Six toothed bars are symmetrically mounted on the front and rear roller and threshing teeth are spirally arranged with 10~ backward titling angle to prevent straw to be hung up.

In order to control the gap of the finger gear and concave plate screen, the connecting plate of the gear rod and roller plate are also designed two inner and outer holes. It fixed inner hole (2) when the machine is leaving from the factory. It fixed outer hole (1) when the finger gear is heavily broken-or need reduce the gap.

Note: 1. It is prohibit to reduce the quantity of the gear rod of front and rear threshing roller.

2. After remove the gear rod, it must tighten the screws and check the balance, otherwise it may occur some trouble.

VI. Adjustment for Convulsionary Screen, See figure 9



1.Convulsionary Screen front rubber 2.Sacking 3. Front sliding plate 4. Auger case body 5. Grain selection Plate 6. Auger case body 7. Bolt 8. Screen Adjustment block 9. Gasket

Figure 9 Adjustment for Convulsionary Screen

This machine use tunable volume reciprocate convulsionary screen.

1. The volume adjustment of screen for Convulsionary screen

It is necessary to adjust the volume of screen when the screen surface loss too much, the auger bear too much and too much sundries in the haversack.


1) The screen is steep (the volume is big), the loss is little but the sundries is too much, the burthen of auger is big and fray quickly for the under convulsionary screen.

2) The screen is flat (the volume is small), the loss is large but the sundries is little, the burthen of auger is small and fray slowly for the under convulsionary screen.

The screen volume is located at the standard place namely the right over of lock nut is aim at the No.2 gear. (Please check with figure 9).

In actual harvesting, we may want to turn up the screen volume when we found the loss is too much. Please at first, open the rear diversion cover, triggering the screen adjustment arm in order to the lock nut can aim at the No. 1 gear. Contrarily, we want to turn down the screen volume when we found the sundries is too much, triggering the screen adjustment arm in order to the lock nut can aim at the No.3 gear. Anyway, the customer can choose different screen volume as the above roles when he got the actual harvesting result.

2. The way for pulling Vibration Screen



When the vibration screen has some trouble, we must pull the vibration screen out of the machine. Please refer the following process:

- 1) Open the rear diversion cover
- 2) Loosen 2 pcs M10 bolt of the bearing seat for two side of rear axle of the vibration screen.
- 3) Drive up the rear of vibration screen, pull out the vibration screen by two persons.

Figure 10

3. Method of installation for vibration screen (See figure 9)

- 1) Rise up the vibration screen as far as possible and push it forward slowly, lock bolts.
- 2) Place the grain selection plate flexibly by the casing of auger
- 3) Place sacking well in front of and at the side of the screen.
- 4) Check: turn the cleaning sprocket by hand the cleaning chamber can be shaken slightly.
- 5) Mount items in reverse order by which they are dismantled.

VII. Tension Adjustment of the Track: (See Figure 11)




Figure 11 Tension for Track

1. Fixing Seat for Guide Wheel 2. Tension Screw 3. Adjustment Nut 4. Stay Bar sleeve 5. Stay Bar 6. Guide Wheel

It is unnecessary to adjust the tension of track frequently. Loose track is beneficial for extending

the track use span except the track is not digression. Tighten the adjustment nut when the track needs tension.

If the track is digression, the reinstall method is: use the jack up digression side frame, loosen the adjustment nut, push the guide wheel to the bottom, then use the tommy bar to reinstall the digressed track on the wheel.

If the track reinstalled that it needs re-tension. The method is: use tommy bar pry back the guide wheel, tighten the adjustment nut to available place.

Notes:

1. The track cannot be too tensioned and it is right only no teeth-jumping occurs.
2. Coat a bit of lubrication oil on the tension screw rod to avoid rust before the machine enters into the field.

VIII. Adjustment of Steering and the Brake, see Figure 12




Figure 12

The steering and brake device is the guarantee for stable and safe running of the harvester. The machine adopts jaw coupling and turning gear plus friction disc brake. When working the power is transmitted via the central gear jaw to the turning gear and then transmitted to the reduce gear at both sides to drive the axle and the track to make the chassis move forward.

Principle: Brake force is controlled by the pressure and stroke of oil cylinder on the gear box. The pressure of oil cylinder has been adjusted when leaving the factory and the stroke has two section. When left and right steering handle turns a small angle, steering oil cylinder will support brake arm to mm a small angle, the tooth of steering gear will split and the machine will make big turn; when left and right steering handle turns further angle, steering oil cylinder will support brake arm to turn further angle, friction disc pressed tight, then achieve one side brake, the machine make emergent turn.

Adjustment: See Fig. 12, Adjustment of Steering and the Brake is the adjustment of clearance between Oil Cylinder and Braking Arm. Normally it is 1-2mm. When the friction disc is worn after using for some time, the oil cylinder needs to be adjusted to be longer, i.e. the clearance between oil cylinder and braking arm should adjust smaller. When the clearance is zero, if the steering is still unavailable, should check whether the pressure of steering oil cylinder is sufficient (Use the method by adding washerΦ5 on hand valve), or consider adding a piece of smooth disc in the brake or replacing the friction disc.

IX. Emergency Brake, See Fig. 12

If the emergency brake is needed when stopping the machine on the slope or emergency needs, it can be done by stepping on the brake pedal, which is located at the side of left foot (See Fig3). When using, step on the brake pedal, use hand to fasten the brake pedal with lock buckle, slowly move away foot, stop engine.

The braking theory (See Fig t2): When step on the braking pedal, the balance band iron will be lifted up by the spring, long link fork will drive the left and right brake arm in front of the gearbox to rotate an angle, and drive the left and right turning forks in the case to twist simultaneously to reach the goal of braking the machine.

Attention: Before restarting the machine, firstly step on the brake pedal, unfasten the brake pedal lock buckle, start the engine, push or pull the main gearshift lever, at the same time slowly release brake pedal (1), the machine will move forward or backward.

X. Adjustment and Maintenance of the Driving System

In the course of application, take care of tightness of the V-shaped belt and the chain. The service life shall be affected if it is too tight and the driving efficiency will be affected if it is too loose. The free flexibility of the loose edge of the chain can be determined by the central distance of two wheels in the range of 5-10 mm and the flexibility of the V-shaped belt can be determined by the central distance of two wheels and by hand pressing with 6 kg in the range of 10-30 mm.

XI. Adjustment and Maintenance of the Hydraulic System (see Figure 13)




Figure 13

1. High Pressure Oil Pipe $\Phi 10 \times 1670$
2. High Pressure Oil Pipe $\Phi 16 \times 1300$
3. High Pressure Oil Pipe $\Phi 16 \times 180$
4. Low Pressure Oil Pipe $\Phi 16 \times 170$
5. High Pressure Oil Pipe $\Phi 16 \times 1300$
6. High Pressure Oil Pipe $\Phi 8 \times 2500$
7. High Pressure Oil Pipe $\Phi 10 \times 500$
8. High Pressure Oil Pipe $\Phi 16 \times 155$
9. High Pressure Oil Pipe $\Phi 16 \times 800$
10. High Pressure Oil Pipe $\Phi 10 \times 1550$
11. High Pressure Oil Pipe $\Phi 8 \times 920$
12. High Pressure Oil Pipe $\Phi 8 \times 830$
- A. E310 Gear Pump
- B. Hydraulic Oil Tank
- C. Infinitive Variable Gear
- D. Oil Radiator
- E. 8MB1 Slide Valve
- F. Oil Cylinder of Reel
- G. 8G Slide Valve
- H. Oil Cylinder of Cutting Table
- I. JZXGB Steering Cylinder

The hydraulic system consists of oil tank, oil pump, combined valve for lifting up/down of the reel and the cutting table, oil cylinders of the reel and the cutting table, high and low pressure oil pipes, connectors and combined pad etc. The overflow pressure of the combined valve for lifting up/down of the reel and the cutting table has been adjusted when leaving the factory and no further adjustment is needed. The oil for the system is special hydraulic oil which shall be better filled to 2/3 of the height, it can be replaced with Mobil 424 or N68 low-condensation anti-abrasion hydraulic oil, however it should be replaced at all, never replace with normal hydraulic oil. When replacing hydraulic oil the oil filter should be replaced as well otherwise troubles caused thereof should be born by customer himself.

Trouble in the hydraulic system normally comes from unclean hydraulic oil. Dismount the system and clean it then mount it again troubles can be removed (lead seal cannot be moved when dismounting).

After changing oil the oil tank should discharge air. The way is to loosen two turns of the oil outlet nut of the hydraulic pump and the oil inlet nut of the lifting up/down oil cylinder of the cutting table, start the engine to operate the hydraulic pump and tighten nuts until no air bubble is found in overflow oil from the oil outlet of the hydraulic pump. When tighten nut close the engine to ensure safety of operation.

XII. Adjustment and Maintenance of the Electric System, see Figure 14

The electric system consists of generator, voltage regulator, start motor, battery, indication instruments, fuse case, lighting, alarm horn, control switches and connection wires. The system is grounded with the negative polarity and the rated voltage is 12V. The electric schematic drawing refers to Figure 14.


Special Attention: the polarities of the system cannot be connected reversely otherwise some electric components in the circuit may be burnt out.

The wire connections are marked with their colours as per the diagram. When repairing, confirm the location of connections by colour mark in wiring diagram (see wiring table for colour codes). In case problem occurs in the electric system, it should make careful analysis as per the schematic diagram, judge and find the location of trouble and make repair or maintenance.

In case trouble in the circuit occurs, first of all check the central electric control box, namely check whether red alarm indicator lamp on driving console panel is on or off, if on, check the corresponding circuit the indicator lamp stands for, after confirming the trouble have solved then can replace the fuse. Only when the fuse and the battery are normal can other items in the circuit then be checked, for example if connector is loosened, if terminal is disconnected.

Wiring Table

Code of Wire Colour	R	G	L	Y	W	B	Or	Pu	Lg	Br
Name of Wire Colour	Red	Green	Blue	Yellow	White	Black	Orange	Purple	Light Green	Brown



Fuse Arrangement**NO.1: Turning Lamp;****NO.2: Horn;****NO.3: Store;****NO.4: Head Lamp, Tail Lamp and Instrument;****NO.5: Safety Switch****NO.6: Store;****NO.7: Store;****NO.8: Store;****NO.9: Generator;****NO.10: Store;****NO.11: Store;****NO.12: Store****NO.13: Empty****NO.14: Empty****NO.15: General Power Source****The normal electric troubles and their remedies are listed in following table:**

Location	Trouble	Cause and Judgment of Trouble	Remedy
Start Circuit	No running of the starter	1. Check whether fuse NO. 15 burns out. 2. Bad contact of wire connections, ground wires or connectors. 3. Battery is seriously insufficient. Insufficient cause no running. 4. Trouble of the start relay, connect the "power supply" (thick red wire) and "motor" (thick blue wire) by the wire, if it can be started, then the start relay is damaged. 5. Trouble of the starter, if some time it can start but sometime it cannot start, it is likely the electromagnet switch is damaged. If there is sound like "DADA" when starting, probably the motor is damaged if the battery is not insufficient. 6. Key switch is damaged, connect 1 (thick black wire) and 3 (thick yellow wire) by the wire, if it can be started, then the switch is damaged.	Reconnect fuse. Insert connector or tighten screws. Recharge in shop nearby. Replace. Replace. Replace.
	Powerless running of the starter	1. Battery is insufficient. 2. Bad contact of wire connections or connectors. 3. It is too cold in winter, shall use 30 CD grade diesel engine oil.	Recharge in shop nearby. Insert connector or tighten screws. Replace 30 CD grade diesel engine oil.
	Driving gear & teeth ring	1. Driving gear on the motor is damaged or flywheel ring gear is damaged.	Replace gear or motor or

	cannot be meshed and abnormal sound occurs	<p>2. Bolts of the starter are loosened and teeth cannot be meshed normally.</p> <p>3. The voltage of battery is less than 11.5V</p>	<p>flywheel.</p> <p>Mount correctly and tighten bolts.</p> <p>Recharge in shop nearby.</p>
	After the engine is started, the starter runs without stop	<p>1. Contact plate of electromagnetic switch :and contacts are sintered.</p> <p>2. Spring of driving fork is too soft or broken to cause iron core and contact plate not be reset.</p> <p>3. Contacts of the start relay are sintered to make two main terminals of the electromagnet switch be always connected.</p> <p>4. The key switch does not reset.</p> <p>Attention: When check the electric trouble, first switch off the generator, open the fuse case cover, and draw out inserts of the fuse at both ends and then check.</p>	<p>Replace damaged parts and components.</p> <p>Attention: in case when such trouble occurs, first switch off the knife of power supply behind the machine.</p>
Charge circuit	No electricity is charged (no indication the ampere meter)	<p>1. Check whether fuse NO.9 burns out; check whether the belt of the motor is too loose.</p> <p>2. Start machine, turn on the lamp, turn off the key switch, then the higher accelerator is, the brighter the lamp will be. When the adjustment indicator lamp is normal, if the lamp is not light, the electric motor probably is damaged.</p> <p>3. Turn on the key switch, press horn, the pointer of ampere meter will deflect to the negative polarity. If no such reaction, the ampere meter must be damaged.</p> <p>4. The regulator burns out just 1 to 2 hours after the engine is started, check whether there is breakage on the yellow wire from regulator to the "+" polarity of generator and the green line to "magnet field". If no breakage, it means the short circuit of generator.</p> <p>5. Start the engine at idle status; connect "power supply" and "magnet field" terminals of the regulator by the wire to see if the ampere meter has reaction. If no change, enlarge the accelerator slowly to rise up speed, if charge current exists it means the regulator is damaged; if still no reaction, it means the generator is damaged.</p> <p>6. Connect the "+" polarity of the generator with one end of the wire, scrape the other end of the wire on the case of the generator. If spark occurs it means the generator is working; if no spark</p>	<p>Reconnect ruse or tighten belt,</p> <p>Replace.</p> <p>Replace.</p> <p>Replace.</p> <p>Replace.</p> <p>Replace.</p> <p>Replace.</p>

		occurs, it means the generator is damaged.	
	Charge current is too small	<p>Symptom: the charge current is always small when engine is at various speeds, the battery is always insufficient, lamp light is dark, horn voice is small, and starter runs powerlessly.</p> <p>Causes Analysis:</p> <ol style="list-style-type: none"> 1. Bad contact of the charge circuit and large contact resistance. 2. The driving belt is sliding, speed of the motor is too low. 3. The diode in the generator is damaged or internal coil has trouble. Check by the test lamp: remove wires from "+" and "F" terminal of the generator, connect them with two leads of the test lamp, start the engine to rise up speed gradually to see the brightness of the lamp. If the lamp light looks red, and brightness cannot be increased along with rising of speed or the brightness increase not obviously, it means trouble is inside the generator. If brightness can be increased greatly along with rising of speed, it means the generator is good, trouble is in the regulator. 4. Contacts of the regulator are dirt or voltage is regulated too low. Check method is same as those of no charge of the generator. 	<p>Tighten, insert all leads tightly or remove rust and oil stain.</p> <p>Adjust the generator and tighten the belt.</p> <p>Replace or repair in shop.</p> <p>Replace</p>
	Charge current is too large	<p>Symptom:</p> <ol style="list-style-type: none"> 1. When the battery is not insufficient, the ampere meter shows charge current is still over 10A. 2. The electrolytic liquid of the battery consumes too fast and should be always added. 3. The light bulbs always burn out. <p>Causes Analysis:</p> <ol style="list-style-type: none"> 1. Voltage limit of the regulator is adjusted too high. 2. Insulation brush of the generator or positive brush is shortly connected with components board. 	<p>Please ask electrician to repair or replace components.</p>
Power Consuming System	Lamp light doesn't	<ol style="list-style-type: none"> 1. Check whether fuse NO.4 and NO.5 burn out. If not, short circuit the dark red wire of headlamp switch with either wire of high-low beam lamp, 	<p>Replace.</p>

		<p>if headlamp doesn't light, it means the headlamp is damaged, if lights, it means the switch is damaged.</p> <p>2. Short circuit those two wires of tail lamp, if not light, it means the tail lamp is damaged, if lights, it means the switch is damaged.</p> <p>3. Fuse burns out immediately after turning on the tail lamp, it means one of the tail lamp is damaged.</p> <p>4. Turning lamp can't light, it must be fuse NO.1 burns out or turning lamp is damaged.</p>	<p>Replace.</p> <p>Replace.</p> <p>Replace.</p>
	Indication meters don't work	<p>1. No indication: check whether fuse NU.4 burns out, if not, switch on the power supply and short circuiting relative sensor, if meter has indication it means the sensor is damaged otherwise the meter is damaged.</p> <p>2. The indication cannot be reset: switch on power supply, the meter indicates the maximum position and when the engine is working, still cannot be reset, then disconnect the sensor first, if the pointer of the meter can return to zero, it means the sensor is shortly circuited, if off the sensor, the pointer of the meter also cannot return to zero, it means the meter is damaged.</p>	<p>Replace relative components.</p> <p>Replace relative components.</p>
	Horn has no sound	<p>1. Check whether fuse NO.2 burns out, short circuit the horn without withdrawing connectors, if has sound, it means switch is damaged, if no sound, it means horn is damaged.</p> <p>2. Short circuit horn button, if has sound, it means horn button is damaged, if no sound, it means born button is damaged, if no sound, it means horn damaged.</p>	<p>Repair or replace.</p> <p>Replace horn.</p>

Note: in principle the whole set of the electric staring system has no warranty and customer should correctly operate it and take care of its maintenance.

4 Work on the Field

I. Preparation of Cutting Way, see Figure 15

This combine harvester should enter into the field from the right corner. In order to reduce loss, an crop area of 3mx4m could be cut at the right corner manually in advance. If the ridge is lower than 10cm. the harvester can directly enter into the field without cutting crop area. After the combine harvester entered into the field, first of all it shall cut along the right side to the end, then run backward 10-15 m to cut diagonally twice or three times in order to turn 90~, then cut diagonally twice or three times as well to mm 90~ further. After that, cut the crop along another

side to the end, to open the lateral Cutting way at another end as the same way. It is worthwhile to remind that: when cutting along the edge, take care the driving part of the cutting table cannot touch the ridge. (See Figure 15A).




Figure 15

II. Operation Routes

Based on structural features and operation habits of this combine harvester, the machine is suitable for operation in counter clockwise rotation. Under certain circumstances, it can also operate in clockwise rotation. Normally there are two operation routes.

1. Four-Sided Cutting Way:

For square or wider width field, after cutting ways are made, four-sided cutting way can be used. Cut one line to the end and rise up the cutting table. When the middle in the track is in parallel with further crop, turn 60° to left; if the tail of the track is above uncut crop, run backward and turn further 30° to left at the same time to turn the machine 90° and the cutting table is just aiming at cutting area. Shift to advance gear and lower down the cutting table to harvest continuously round by round until all crop is harvested (See Figure 15B). If the field has a larger area, use the four-sided cutting way to cut 3-4 rounds then insert the field in the middle to divide it into two or three rectangular fields, then cut crop by the two-sided cutting way.

2. Two-Sided Cutting Way:

It is suitable for the field with longer length but short width. First of all cut crop by the four-sided cutting way to cut 3 rounds, i.e. to cut the lateral way about a width of 5 m, then cut crop along the longwise to the end without run backward, and then to left directly to cut other side of the cutting area. By means of this way no running backward is needed and cutting efficiency can be fully brought about. Anyway the operator should be good at summarize experience to create practical operation method based on different condition of fields (See Figure 15C).

III. Operation on the Field

1. Selection of the Accelerator of the Engine in Operation:

This combine harvester should keep operation under large accelerator no matter it is in operation or in turning at the end of the field, otherwise troubles such as blockage of the

vibration screen or spreading of grain could occur.

2. Running on Straight Line When Cutting as Can as Possible:

This machine should run on straight line when cutting crop as can as possible, otherwise the rubber track could press down some uncut crop to cause manmade loss. Avoid cutting plus turning as can as possible to cause loss of pressed crop. Those remained uncut crop at the corner can be cut manually after crop on the large area is harvested then can be evenly spread (without piling up) on uncut crop.

Chapter 5 Lubrication of Combine Harvester

The lubrication of the engine shall be strictly according to the instruction of the engine. The lubrication of the combine harvester can be done as following table:

Part	S/N	Lubrication	Oil Filling Interval	Lubricant
Cutting Table	1	Cut edge pressers and press plates of slide groove	2 hours	Machine Oil
	2	Cutter lever bearings	4 hours	Machine Oil
	3	Rotating parts under support arms connected with cutting	8 hours	Machine Oil
	4	Driving chain and extension draw teeth	4 hours	Machine Oil
	5	Bearing seat of auger on cutting table	1 season	Grease
	6	Bushing crank arm Of auger on cutting table	8 hours	Grease
	7	Self-aligning bearing on eccentric mounting of upper and lower cutting tables	1 season	Grease
	8	Swing bar bearings on cutting blades	1 season	Grease
	9	Rotating parts of reel bars	4 hours	Machine Oil
Conveyor	10	Rotating parts on both ends of swing axle of driven	4 hours	Machine Oil
	11	Bearing of driven wheel	1 season	Grease
	12	Conveying chain	1 shift	Grease
	13	Left and right bearing on he rotating parts of main	1 season	Grease
Threshing and Separating Device	14	Bearing of Tension wheel	1 season	Grease
	15	Gear box and chain box of auger	1 season	Grease
	16	Bearings on both ends of front and rear rollers shaft	1 season	Grease
	17	Bearings on both ends of front and rear fans shaft	3 shifts	Grease
	18	Bearings on both end of horizontal No. 1 and No. 2	3 shifts	Grease
	19	Bearings on both end of vertical No.1 and No. 2 augers	3 shifts	Grease
	20	Two small bearings in the front of vibrating screen	1 season	Grease
	21	Bearings on eccentric shaft of vibrating screen	1 season	Grease
	22	Chain of vibrating screen	1 shift	Machine Oil
	23	Beatings on central driving shaft	1 season	
Chassis	24	Bearings of support wheel	1 season	
	25	Bearings of guide wheel	1 season	
	26	Bearings of support wheel	1 season	
	27	Bearings of tension wheels of all belts	3 shifts	

	28	All articulated points of operation levers	1 shift	
	29	Throttle cable, stop switch wire	1 shift	Machine Oil
	30	Gearbox	1 season	No.68 low-condensation anti-abrasion hydraulic oil
	31	Hydraulic oil tank	1 season	No.68 low-condensation anti-abrasion hydraulic oil

Note: Damage of other parts caused by damage of bearings is not covered by the warranty of the factory.

Chapter 6 Running-In of Combine Harvester

New machine or the machine after overhaul should have running-in operation before putting into application and running-in contents are as follows:

1. Before running-in operation, first rotate the machine manually to check all working parts. Only everything is normal can the machine be put into unload operation.
2. Start the engine and close the work clutch, set the accelerator from small to large to listen if abnormal sound exists. Check if lifting up/down of the cutting table is normal for 5 minutes.
3. Unload running on plain road with all shift gears for 10 minutes respectively, check adjusted turning, engaging/disengaging and braking as well as check all fasteners if loosened, check all welded parts if seam or off-welding occurs and solve problem in time if it is found.
4. Select the field with low yield to make running-in operation by controlling cutting width, forward speed and light load for the time no less than one shift (8-10 hours).
5. Make full-load running-in operation on the basis of light load running-in for the time no less than one shift.
6. After finish full-load running-in, make overall inspection, adjustment and tightening on the machine, discharge lubricant oil from the variable gearbox, clean it with diesel oil and fill in new lubrication oil. The hydraulic oil shall be replaced as well.
7. New engine or the engine after overhaul should have running-in operation according to stipulations on the manual of the engine.

Chapter 7 Maintenance of Combined Harvester

1 Shift Maintenance of the Engine

Besides making maintenance according to stipulations in the manual of the diesel engine, the engine shall have following jobs to do:

1. Remove dust and straw bits on the radiator. As the harvester works under a bad condition, especially wheat harvester season, lots of dust and straw bits will stuff on the radiator when harvesting and affects heat radiation of the water tank therefore it should be cleaned before starting operation. Besides, when harvesting, always check the blockage of straw bits on the engine cover to keep the air flow.
2. Clean the air filter. As the same reason the air filter is also easy to be ineffective. If the filter

screen is blocked, at least power of the engine shall be reduced and black smoke emitted under large load, even worse the engine will be hardly to start, therefore it should be maintained strictly as per the manual of the engine. If affected by wind direction or much dust, cleaning times should be increased.

3. Check whether the water inlet of engine is broken, if there is leakage of water; Check whether air inlet of engine has crack, if the dust can enter.
4. Check whether battery has electricity, whether the rubber bush on the battery post is broken.

2 Shift Maintenance of the Combined Harvester

1. The machine should keep good technical conditions and all parts should be adjusted well as per technical requirement.
2. Check whether the function of handle for left and right turning, braking is in good condition. Operate with trouble is strictly prohibited.
3. Check the lubrication system of the combine harvester and fill oil in time as per requirement.
4. Check if bolts, nuts and other fasteners are loosened.
5. Check if all welded parts have seam or off-welding, correct and repair deformed and damaged parts.
6. Check all operation parts to see if they are flexible and reliable.
7. Make trial running before operation to see if abnormal condition exists, especially on the driving parts of the cutting table and the vibrations screen parts.
8. Fill enough oil in the engine and enough water in the water tank, bring together the extinguisher, accompanied tools and lubrication oil to start the machine.

Note: When welding is required by repairing, knife switch of power shall be pulled down and all straw bits and oily dirt around the welded parts should be wiped out so as to prevent catching fire.

3 After-Season Maintenance of the Combined Harvester

After working for a season the machine should have an overhaul so as to prolong the service life of the machine and to make preparation for application in the next season.

1. Clean out all impurities, soil, sand and grain in the auger.
2. Fill new lubrication oil in all rotating parts, bearings and gearbox according to requirement of lubrication.
3. Make an overall check upon the harvester and repair or replace all damaged or worn parts, in which:
 - 1) Check and adjust the cutter:
 - a. The working plane of the edge protector should be in a same plane and tile non-coplanarity of three neighbouring working planes should be not larger than 0.5 mm.
 - b. When the moving blade is above the edge protector, there should be a clearance not larger than 0.5 mm at the front end of the both and a clearance of 0.3 - 1.3 mm at the rear end.
 - c. The clearance between the edge presser and the moving blade should be not larger than 0.5mm and that and the blade bar not larger than 0.2 mm.
 - d. Check riveted moving cutter if it is loosened or has many lost teeth (the cutter with one third lost teeth should be replaced), check if bolts of the edge protector are loosened.
 - e. Manually moving cutter, it should be flexible. If blocked or loosened, can adjust the edge presser and friction disc and the friction disc on the press plate of the slide groove. Loosen the

bolt and move the edge presser, friction disc and the friction disc on the press plate of the slide groove forward and backward to adjust front and rear clearances of the cutter. Increase or decrease pads under the friction disc to adjust upper and lower clearances of the cutter.

f. Check the knuckle bearing of the long connecting rod if it plays due to worn-out, if the clearance between two bearings in the blade bar holder and the friction block is larger than 0.3 mm. If so, replace immediately.

2) Check and replace conveying rake teeth.

- a. Fixing bolts of conveying rake teeth should not be loosened.
- b. The tightness of two conveying chain should be consistent with each other, and should fill with grease.
- c. Driving and driven wheel should work smoothly. No blockage should occur.

3) Check and replace the threshing roller as following:

- a. The clearance between teeth bar of threshing roller and concave board should be 15-18mm, (when the concave board can be judged not deformed), if the clearance is larger than 25mm, should dismount teeth bar, install on outer holes or replace teeth bar.
- b. Front and rear concave board should not be deformed or dropped seriously.
- c. Vibrating screen pieces should not be split, broken and lost. Grain selecting nylon soft plate, canvas should not be broken or lost.

4. Check whether all warning marks are clear and complete, if not, replace or add it immediately.

5. For those parts with paint-lost or rusted, they should be repainted after removing rust.

6. Coat anti-rust grease on the cutter and chains.

7. Loosen all driving belts and conveying chain. If the machine not use for a long time, the rubber track also should be loosened.

8. Disengage the work clutch.

9. The storage place should be dry and well-ventilated, open storage is not allowed.

10. Always make check in rainy days and wet seasons.

11. If the machine will not be used for a long term the battery should be maintained as per one of following two ways:

1) **Dry Storage Way:** recharge the battery sufficiently then discharge it in 20 hours until the final voltage is 1.75V, dump out the electrolytic liquid and soak it in distilled water for 3 hours, dump it out again and soak again in distilled water until no acid liquid is extracted, then dump out water from the battery and tighten the cover of the filling hole, seal the vent with wax and store it in room. The storage place should be dry and well-ventilated with temperature constantly between 5 °~40 °, over 1 m far from heat source such as sunlight or as per instruction manual of the battery manufacturer. When using the battery in dry storage way, it shall be done as that of new battery.

2) **Wet Storage Way:** charge the battery sufficiently and seal the vent on the filling hole, then store it in dark place. Regularly check the density of electrolytic liquid and check its discharge degree by the high rate discharge meter. If the volume is lower than 25%, it shall recharge immediately, or make recharge once every one or two months. Normally the storage time for this way shall be no longer than six months.

Note: when using, take out the seal from the vent otherwise the battery shall be exploded.

Chapter 8 Troubles and Remedies

Following normal troubles are mainly from operation and maintenance not according to stipulated methods, no clearing of straw, grass or mud in time and bad adjustment of all moving parts.

Part	Trouble	Causes	Remedies
Cutting Table	Cutting speed reduced, crop cannot be cut, or is drawn up with roots, leak cutting of crop.	<ol style="list-style-type: none"> 1. Large clearance between blades. 2. Edge protector and moving and fixing blades are damaged. 3. The installation position after repairing not matches with the requirement. 4. Much feed volume or speed of the diesel engine not enough, driving belt loosening. 5. Much grass and soil on the cutter. 	<p>Adjust clearance of blades. Repair or replace.</p> <p>Adjust as per section 2.</p> <p>Reduce speed to run forward, enlarge accelerator of diesel engine and tighten driving belt. Remove.</p>
	Cutter doesn't work	<ol style="list-style-type: none"> 1. Objects are between moving and fixing blades. 2. Driving belt loosened or driving chain broken. 	<p>Readjust clearance of blades after repairing. Repair or replace.</p>
	Abnormal sound in swinging bar	<ol style="list-style-type: none"> 1. Knuckle bearing of long connecting rod plays due to worn-out. 2. Clearance of two bearings in the blade bar holder and the friction block is larger than 0.3mm. 	<p>Replace knuckle bearing.</p> <p>Reshape or replace bearings or friction block.</p>
	Auger of the cutting table is blocked.	<ol style="list-style-type: none"> 1. Much feed volume. 2. Base plate of cutting table is deformed due to be bumped. 3. Auger is blocked. 4. Driving belt is loosened. 5. Natural height of crop is less than 500mm. 	<p>Reduce forward speed or cutting width.</p> <p>Adjust clearance between base plate and blade of auger.</p> <p>Clear grass, fill oil in slide block and bearing.</p> <p>Tension belt.</p> <p>Lower the stubble, lower and move inside the reel wheel or change field.</p>
	Throw straw at the joint of cutting table and conveying groove.	<ol style="list-style-type: none"> 1. Unsuitable adjustment of reel fingers of the auger on cutting table. 2. Much feed volume. 	<p>Adjust as per requirement of the manual.</p> <p>Reduce feed volume.</p>
	Throw straw by the reel	<ol style="list-style-type: none"> 1. Reel is too lower. 2. Angle of reel teeth is improperly adjusted. 3. Adjusting nut of reel teeth is loosened. 	<p>Adjust higher.</p> <p>Adjust to droop down vertically.</p> <p>Tighten after adjustment.</p>

Middle Conveying	Feed inlet of conveying groove is blocked.	<ol style="list-style-type: none"> 1. The place of adjusting block of auger on cutting table is improper or driving belt of conveying is too loose. 2. The blades of auger on cutting table is deformed and not in the right place. 3. The crop fed in is too short. 	<p>Readjust or tighten driving belt of conveying as per requirement of manual.</p> <p>Reshape.</p> <p>Lower the stubble, lower and move inside the reel wheel.</p>
	Straw returns in conveying groove.	<ol style="list-style-type: none"> 1. The crop fed in is iii, too soft or too wet. 2. The straw rib on the cover of front roller is deformed, dropped or worn-out. 3. Bush roll with driving wheel. 4. Conveying chain is too tight. 	<p>Raise the stubble or change field to work.</p> <p>Repair or replace.</p> <p>Refasten.</p> <p>Adjust the conveying chain.</p>
	Grass wound on driven wheel holder or on anti-wrap holder.	<ol style="list-style-type: none"> 1. Crop is not mature or too wet. 2. Too soft after stem of crop get ill or much grass. 	<p>To harvest some days later.</p> <p>Change field to work.</p>
Threshing Roller	Blockage of threshing roller.	<ol style="list-style-type: none"> 1. Stems too wet or crop is not mature. 2. The straw rib on top cover is deformed and worn out seriously. 3. 5-in-1 belt is too loose or power of diesel engine is insufficient. 4. Iron sheet at the grass discharge outlet is deformed and blocked. 	<p>Select mature and dry crop.</p> <p>Reshape or replace.</p> <p>Tighten 5-in-1 belt or enlarge the accelerator.</p> <p>Reshape and repair.</p>
	Much grass involved.	<ol style="list-style-type: none"> 1. Crop is too wet, holes of concave are blocked. 2. Low speed and insufficient power of roller. 3. Concave board is deformed or clearance between spike-teeth and concave board is too large. 4. Crop is hardly to threshing or not mature. 	<p>To harvester after it is dried.</p> <p>Enlarge the accelerator to maximum.</p> <p>Reshape the concave board or adjust the clearance of concave board.</p> <p>Change field to work.</p>
	Severe loss from screen.	<ol style="list-style-type: none"> 1. The opening volume of screen plates is too small. 2. Blockage between upper screen plate and lower screen. 3. 5-in-1 belt too loose and speed is not enough. 4. Much feed volume. 	<p>Enlarge tile opening volume of screen plats as per instruction manual.</p> <p>Take out and clear.</p> <p>Tension 5-in-1 belt.</p> <p>Slow down the forward speed.</p>

		5. Fan blades are deformed or air duct is blocked.	Check and repair.
	Abnormal sound in vibration screen.	1. Screen plate is broken or dropped or construction bolts of guide track are loosened. 2. Bearing is damaged.	Replace, repair or tighten. Replace.
	Many impurities in grain case.	1. Adjusting bolt of screen plates is loosened. 2. Blades of front fan are damaged. 3. Opening volume of screen plates is too large. 4. Iron wire of concave board is broken.	Adjust opening volume of screen plates and then tighten bolts. Replace or repair. Turn down the opening volume of screen as per instruction manual. Replace or repair.
	Grain discharge auger is blocked.	1. No responsibility, grain case is too full. 2. Stems of crop are wet and crop is not matured. 3. Blades of auger are deformed or belt is loose.	Strengthen responsibility. Reduce feed volume. Repair or tighten belt.
	Grain discharge auger and auger roller are seriously worn out.	1. Opening volume of screen plates is too large and impurities are too many. 2. Auger is not straight and scraps with auger roller.	Turn down the opening volume of screen plates as per instruction manual. Straighten the auger.
	Breakage rate is increased.	1. Opening volume of screen plates is too large, No.2 auger deals too much quantity. 2. Blades of auger are deformed or grain discharge auger is blocked. 3. Variety reason.	Turn down the opening volume of screen plates as per instruction manual. Repair or deal as the blockage of auger. Change field to work.
Chassis	Track off the rail.	1. Track sunk in ditch of wheat and turning 2. Sudden turning. 3. Walk on slope over 5 ° or concave road. 4. Pass through ridge diagonally over 25 ° 5. Track is not tightened. 6. Support pipe of guide wheel is bent.	Work by crossing on the ditch, Turn at low speed. Walk S line at low speed. Pass through ridge vertically. Tighten the track as request. Repair or replace.
	Edge of support wheel is deformed with crack.	1. Bearing of support wheel is seized due to lack of oil. 2. Walk on uneven road for long time. 3. Walk on uneven road too fast and make sudden turn.	Lubricate after repairing. Load on truck if far from 4 km. Turn with small accelerator at low speed and reduce speed.

	Guide wheel, support wheel are badly worn-out.	<ol style="list-style-type: none"> 1. Bearing is seized due to no oil for long time. 2. Screw lost and oil seal ineffective. 	<p>Fill oil and replace.</p> <p>Repair and replace.</p>
	Turning out of control.	<ol style="list-style-type: none"> 1. 4-in-1 belt of walk clutch is loosened. 2. Turning friction disc is badly worn-out. 3. Turning fork is worn out. 4. Mud on chassis and straw gathered on driving wheel. 5. Force of top bar of turning oil cylinder is insufficient. 	<p>Tighten 5-in-1 belt as request.</p> <p>Readjust length of oil cylinder or replace friction disc.</p> <p>Replace.</p> <p>Clear out mud and straw.</p> <p>Check pressure of combined valve (spring force).</p>
	Walk gearbox broken.	<ol style="list-style-type: none"> 1. Fixing bolts between case and frame are loosened. 2. Often bump with the ridge when reverse. 3. Shift-gear operation with much force. No stop in middle position. 	<p>Replace.</p> <p>Replace.</p> <p>Replace and change operate habit.</p>
	Walk sliding.	<ol style="list-style-type: none"> 1. Sunk depth over 25 cm. 2. Belt of walk clutch is loosened. 3. Chassis has much soil and straw. 	<p>Change field to work.</p> <p>Tension the belt.</p> <p>Clear straw and soil.</p>
Hydraulic System	Output shaft of infinitive variable gear worn out too fast.	<ol style="list-style-type: none"> 1. Main gearshift lever is pulled too fast and no stop in middle position. 	<p>When main gearshift lever at the middle of S groove, it should stop for 1-2 seconds before pull it backward.</p>
	When handle in middle position the cutting table cannot stop.	<ol style="list-style-type: none"> 1. Self-lock of valve ineffective. 2. Top bar of hydraulic control is seized and cannot lower down. 3. Oil leak in upper screw plug, pipe connector of oil outlet of hydraulic assembly and connector of oil cylinder. 4. Oil leak at end of oil cylinder. 	<p>Replace steel ball. Take care when mounting ball, press the surface of ball by copper bar and knock by iron hammer one or two times; remove screw plug and take out top bar of hydraulic control to clean then remount; replace concerned O-ring or combined washers.</p>
	Cutting table cannot be lifted or can be lifted slowly.	<ol style="list-style-type: none"> 1. Oil pump is damaged. 2. Oil level in tank is too lower. 3. Insufficient pressure of combined valve or pressure spring is broken. 4. Oil pipe is aged or blocked. 5. Oil temperature is too high and oil 	<p>Replace with new pump.</p> <p>Fill oil to suitable height.</p> <p>Add one washer or replace spring.</p> <p>Replace oil pipe, clean oil filter and oil tank.</p> <p>Cool or replace hydraulic</p>

		viscosity is insufficient.	oil.
	Cutting table cannot be lowered.	<ol style="list-style-type: none"> 1. Check as per reasons that cutting table cannot be risen up. 2. Top bar of hydraulic control is seized at the lowest part. 	<p>Take relative measures to remove troubles.</p> <p>Remove screw plug and take out top bar of hydraulic control, clean it and then mount it.</p>
	Noise and powerless to walk.	<ol style="list-style-type: none"> 1. Oil suction pipe is deformed or oil filter is blocked. 2. Oil temperature is too high due to oil radiator is blocked by straw bits. 3. Oil viscosity cannot meet requirement or oil is too dirt. 4. Oil level in the tank is too lower. 	<p>Clean and remove dirt, replace new oil if necessary. Note: when replacing oil, clean oil tank and replace oil strainer. Clear straw bit.</p> <p>Replace with No.68 low-condensation anti-abrasion hydraulic oil or Mobil 424 oil. Fill oil to suitable height.</p>

Note: troubles of the diesel engine and rubber track can refer to operation manuals of manufacturers.

Chapter 9 Transportation of the Combined Harvester

As the machine has a lot of square pipe, angle iron and thin plate pieces, therefore it should take care of following points when it is in transportation so as to avoid damage of machines or parts.

I. Load and Transport the Whole Machine

1. Put soft non-metal matters such as wood board or straw bag under the cutting table so as to avoid bumping and deformation.
2. Ropes or iron wires should be fixed on round ring or square pipes on frame and not be allowed to tie on those parts such as thin-wall piece, angle iron or the like.
3. Put wooden block or brick under the rubber track to avoid replacement of the whole machine, tension the shift-gear lever and the brake.
4. Always check the machine if it is loosened, if off-welding or seam occurs in transportation and take relative measures if necessary.

II. Self-Walking Transfer

1. Walk on plain road and take high or middle accelerator.
2. Walk on uneven road with lower speed.
3. Walk forward with lower shift-gear under the command of somebody when turning, ascending or descending, load or unload on truck or steamer (those below 10 tons is strictly prohibited).
4. No heavy weights are allowed to load on the harvester.

Appendix 1

Regular Check and Adjustment Table

Check Point	Standard	Key Points	Interval of Check and Replacement
Cleaning and replacement of fuel oil filter	-----	-----	Check every 100 hours and maintain every 200 hours
Cooling water of engine	-----	-----	Check every 10 hours
Replacement of machine oil of engine	-----	-----	Replace after first 50 hours and every 150 hours thereafter
Cartridge of air filter	-----	-----	Clean every 20 hours and replace every 120 hours
Adjustment of clearance of blades of cutter	-----	front \leq 0.5mm, rear \leq 1.3mm	Check every 50 mu
Spiral conveyor of cutting table	-----	Shortest at the inlet, do not scrape the base plate	Check every 30 mu
Clearance between friction disc of toothed bar holder and bearing	-----	\leq 0.3mm	Check every 50 mu
Knuckle bearing	-----	\leq 1.5mm fluctuate up and down	Check every 50 mu
Conveying chain	-----	Nor too tight but no teeth-jumping	Check every 50 mu
Chains of augers and vibration screen	3-6mm	Naturally drooping	Check every 50 mu
Chains of horizontal and vertical augers	1-3mm	Pull the tension wheel outward	Check every 50 mu
Chains of front and rear rollers and middle axle	5-10mm	Naturally Drooping	Check every 50 mu
Belt of middle axle, fan and auger	0-10mm	Tightness by hand pressing	Check every 50 mu
4-in-1 belt conveying groove	0-5mm	Tightness by hand pressing	Check every 50 mu
4-in-1 belt of walking clutch	0-10mm	Tightness by hand pressing	Check every 50 mu
Belt from driving axle of conveying groove to driving axle of cutting table	5-10mm	Tightness by hand pressing	Check every 50 mu
5-in-1 belt from engine to middle axle	-----	Handle of wok sensor	Check every 50 mu
Track	15-25mm	Clearance of second support wheel	Check every 150 mu
Bolt of bearing seat of middle	-----	Tighten forcibly by	Check every 100 mu

driving axle		spanner	
Connecting bolt of toothed bars of threshing roller	-----	Tighten forcibly by spanner	Check every 100 mu
Bolt of bearing seat of threshing roller	-----	Tighten forcibly by spanner	Check every 100 mu
Clearance between threshing roller and concave board	15-18mm	Measure with measuring tape	Check every 100 mu
If bolts in all parts are tightened	-----	Visually view of spring pad is loosened	Check every 30 mu
Bearing of Walking wheels	-----	Filling grease	Check every season
If warning mark and sign fall off	-----	Clear and right	Check every season
All augers and auger blade	Φ 125	with 2mm abrasion	Check every 500 mu and replace 1000 mu

Appendix 2

The main vulnerable parts list

S/N	No. of drawing	Name	Qty	Remarks
1	T2301	HST Oil filter	1	Replace every 400 hours
2	56015107	W40×80J filter		Clean every 50 hours
3	XINCHANG 480B-32000	Diesel engine oil filter	1	Replace after first 50 hours and every 100 hours thereafter
4	XINCHANG 480B-24000	Diesel engine diesel oil filter	1	Replace every 100 hours
5	4LZ-2.0D.11-6	Track (400×90×48)	2	
6	4LZ-2.0D.11-4	Driving wheel	2	
7	4LZ-2.0D.11-3	Long bracket against dropping	2	
8	4LZ-2.0D.11-2	Short bracket against dropping	2	
9	MC60×85×17	Seal ring	2	
10		Speed adjustment wire harness	1	
11		Flameout wire harness	1	
12	4LZ2.0D.11-1	Reel teeth	40	
13	4LD1.5Z.1.2-1	Reel teeth axle tube	15	
14	GB1211	II type moving cutter	26	
15	GB1211	Single cutter guard	1	
16	GB1211	Double cutter guard	13	
17	4LZ2.0D.1.10-4	Cutter stop block	1	
18	4LZ2.0D.1.10-3	Cutter slide block	1	
19	GB1212	II type Edge presser	5	
20	GB1213	II type friction plate	6	
21	4LZ2.0D.1.10.1-2	Base plate	2	
22	4LZ2.0D.2.4-1	Rake tooth	20	
23	/	30A Fuse	1	
24	4LZ2.0D.1.10.1	Moving cutter assembly	1	
25	4LZ2.0D.6.2.1	Welded grain horizontal auger	1	
26	4LZ2.0D.6.5.2.1	Welded grain vertical auger	1	
27	4LZ2.0D.7.2.1	Welded Residues horizontal auger	1	
28	4LZ2.0D.7.3.2	Welded Residues vertical auger	1	
29	4LZ2.0D.7.3.1-2	Bevel gear	2	
30	4LZ2.0D.7.3.2-3	Scrape plate block	1	
31	4LZ2.0D.4.4.1	Welded screen plate	24	
32	4LZ2.0D.4.4.2	Adjusting screen plate	2	
33		9J-4-1420 Engine ~ HST	1	
34		9J-4-1470 Threshing roller ~ Conveying groove		

35		9J-5-1330 Engine ~ Middle axle	1	
36		B3353 Conveying groove ~ Driving axle of cutting table	2	
37		B1448 Auger of cutting table ~ Reel wheel bridge	1	
38		B2311 Reel wheel bridge ~ Reel wheel	1	
39	L504-AV15-1060Li	Cooling fans of diesel engine	1	
40		Chain C2060L-4L×80+2	2	
41		Chain 08B-1×40	1	
42		Chain 08B-1×92	1	
43		Chain 08B-1×50	1	
44		Chain 10A-1×134	1	
45		Chain 12A-1×178	1	
46	4LZ2.0D.1.2-2	Right eccentric bracket	1	
47	4LZ2.0D.1.2-9	Left eccentric bracket	1	
48	4LZ2.0D.1.2-3	Bushing block	1	
49	4LD2-01-411	Guide bushing	12	
50	4LZ2.0D.7.3-1	Bevel gear	1	
51	4LZ2.0D.7.3.1-2	Bevel gear	1	
52	4LZ2.0D.1.2-11	Extension reel teeth seat	12	
53	4LZ2.0D.11.4-1	Jockey Pulley	2	
54	4LZ2.0D.1.6-6	Balance staff	1	
55	4LZ2.0D.1.6-5	Screw tap axle	1	
56	4LZ2.0D.2-4	Nylon tension wheel	6	
57	4LZ2.0D.1.3.4-1	V-belt tension wheel	2	
58	4LZ2.0D.3.5.2	Welded Rear threshing roller teeth rod II	3	
59	4LZ2.0D.3.5.1	Welded Rear threshing roller teeth rod I	3	
60	4LZ2.0D.3.2.1	Welded Front threshing roller teeth rod I	3	
61	4LZ2.0D.3.2.2	Welded Front threshing roller teeth rod II	3	
62	4LZ2.0D.3.4	Welded front threshing roller concave	1	
63	4LZ2.0D.3.7	Welded rear threshing roller concave	1	
64	4LZ2.0D.3-15		1	
65	/	All bearings		
66	/	All oil seal		

Appendix 3

4LZ-2.0D Track Full-feed Rice Combine Harvester

V-belt

S/N	Installation Position	Specification	Qty	Remarks
1	Engine ~ HST	9J-4-1420	1	
2	Threshing roller ~ Conveying groove	9J-4-1470	1	
3	Engine ~ Middle axle	9J-5-1330	1	
4	Conveying groove ~ Driving axle of cutting table	B3353	2	
5	Middle axle ~ Fan ~ No.1 horizontal auger	B2388	2	
6	Auger of cutting table ~ Reel wheel bridge	B1448	1	
7	Reel wheel bridge ~ Reel wheel	B2311	1	
8	Fan belt of engine	L504-AV15×1060Li	1	

Chain

S/N	Installation Position	Specification	Qty	Remarks
1	Conveying groove	C2060L-4L×80+2	2	1/2' 38.10mm
2	Grain horizontal auger ~ Grain lifting auger	08B-1×40	1	1/2' 12.70mm
3	Residues horizontal auger ~ Residues lifting auger	08B-1×50	1	1/2' 12.70mm
4	Driving axle of cutting table ~ Auger of cutting table	08B-1×92	1	1/2' 12.70mm
5	Grain horizontal auger ~ Residues horizontal auger ~ Vibrating screen	10A-1×134	1	5/8' 15.875mm
6	Middle axle ~ Front threshing roller ~ Rear threshing roller	12A-1×178	1	6/8' 19.05mm
7	Grain unloading horizontal auger ~ Grain unloading lifting auger	08B-1×47	1	1/2' 12.70mm

Note: As the products is always improving, when the actual dimension cannot match with the data in the table, please subject to the actual dimension.

Appendix 4

Accessories list

S/N	No.	Name	Qty	Remarks
1	GB4351-97	MFZ/ABC1 Fire extinguisher	1	
2	/	CA141 rearview mirror	1	
3	GB1211	II type moving cutter	4	
4	GB1210	II type Triplicate cutter guard	1	
5	GB1210	II type Double cutter guard	2	
6	GB867	Cup head rivet 5×14	4	
7	GB867	Cup head rivet 5×16	4	
8	GB867	Cup head rivet 5×22	4	
9	GB867	Cup head rivet 5×25	4	
10	GB867	Cup head rivet 5×18	4	
11	GB1212	II type Edge presser	1	
12	GB1213	II type friction plate	1	
13	4LZ2.0D.2.4-1	Rake tooth	2	
14	/	30A Fuse	1	
15	/	T23C01 Oil filter	1	
16		W40×80J filter	1	
17	XINCHANG 490B-32000	Diesel engine oil filter	1	
18	XINCHANG 490B-24000	Diesel engine diesel oil filter	1	
19		C2060-4L CL Chain full joint	2	
20		C2060-4L OL Chain half joint	2	
21		12A-1 CL 6/8' Chain full joint	2	
22		12A-1 CL 6/8' Chain half joint	2	
23		10A-1 CL 5/8' Chain full joint	2	
24		10A-1 CL 5/8' Chain half joint	2	
25		08B-1 CL 1/2' Chain full joint	2	
26		08B-1 CL 1/2 Chain half joint	2	
27		Crowbar	1	
28		Stand Cutter	1	For Cole

Appendix 5

Attachment tools list

S/N	No.	Name	Qty	Remarks
1	/	Tool case	1	
2	SG216-80	Hammer (2b)	1	
3	GB1432-78	“-“ Screwdrivers 150×7	1	
4	GB1433-78	“+“ Screwdrivers150×8	1	3#
5	GB4440-84	Adjustable spanner 250	1	
6	GB4388-84	Double-ended spanner 10-12	1	
7	GB4288-84	Double-ended spanner 12-14	1	
8	GB4388-84	Double-ended spanner 13-16	1	
9	GB4388-84	Double-ended spanner 14-17	1	
10	GB4388-84	Double-ended spanner 17-19	1	
11	GB4388-84	Double-ended spanner 18-21	1	
12	GB4388-84	Double-ended spanner 22-24	1	
13	GB4388-84	Double-ended spanner 24-27	1	
14	/	Pressure oilcan	1	
15	JB/T7942.1-95	Press bar type grease gun B200	1	
16	GB6295.1-86	Wire-cutter 180	1	
17	GB6293.1-86	Sharp-nose pliers 180	1	
18	GB5356-85	Internal hexagonal wrench 8mm	1	
19	GB5356-85	Internal hexagonal wrench 6mm	1	
20	GB5356-85	Internal hexagonal wrench 5mm	1	
21	/	Straight tip internal circlip pliers	1	
22	/	Curved nose internal circlip pliers	1	
23	/	Straight tip external circlip pliers	1	
24	/	Curved nose external circlip pliers	1	
25	GB3390.2	Socket sets(10-24)	1	